

HUMAN PRIMARY CELLS RULES

1. Operator must notify to Cell Culture Staff the intention to work with H.P.C. in order to receive specific instructions.
2. Operator must work in reserved space only (cell culture room build. 9) and sign IN & OUT.
3. Gloves and lab coats (both disposable) must be used at any time and discarded when operator leave the hood. Protective glasses are advisable during particular work phases.
4. A dedicated set of pipettes is available in the hood's drawer.
5. Glassware should be avoided. DPBS in plastic bottles (marked H.P.C.) and disposable Burker chambers are available in cell culture room (build.9).
6. Solid waste must be discarded in a H.P.C. dedicated ecobox, that should be temporarily closed at the end of work session.
7. Sharp items and needles should be avoided. If it is not possible, they must be handled with care and discarded in the yellow container under the hood. When full, the container must be closed and discarded in the ecobox.
8. Vacuum system cannot be used. Liquid waste and tips must be discarded in the bottle under the hood and inactivated with Sekusept or bleach (10%). At least once at week, bottle must be tightly closed and discarded in the ecobox.
9. At the end of each work session, operator must clean carefully with Pharmacidal or Incidur all the surfaces, close the hood and switch ON the UV lamp.
10. Cells can leave reserved space as frozen vials, lysates or fixed slides only.